



Bradcot Inflatable Awnings

ADVICE ON BOWING LEG BEAMS

Whilst inflating, it is good practice to assist the awning by lifting the canvas “up and out” from each front corner/side once the piston pump has kicked in. (That’s the noisier tone you hear after a short delay in the pumps cycle). Doing this will avoid the front legs being dragged along the ground and stop any tendency for the front legs to bend.

The air bladders will sometimes retain their position from the previous time the awning was inflated, so if you feel the legs are still slightly bowed after following the instructions above, you can most likely change the position manually by getting on your hands and knees!

With your right hand around the back of the beam pull the bottom in towards you. At the same time with your left hand positioned approx half a metre up the leg, push it out towards the front of the awning. Ideally it would be best to do this whilst inflating as explained above.

For any further advice or tips on how to get the best fit to your caravan, please feel free to send photos to info@bradcot-awnings.co.uk. In order to resolve any queries you may have, we would need to see both a side and front view of the awning in situ and pegged under tension. The photos will need to show the full height of the awning including the roof and the pegs.

Thank you

THE BRADCOT TEAM