

Fitting an Inner Tent to a Bradcot Annexe

(All models)

NOTE: The Annexe must be fully tensioned and pegged before fitting your Inner Tent.

1. Make sure the Inner Tent is positioned with its zip facing into the awning.
2. Attach one of the tapes/elastics to each of the 4 corner roof tabs of the Inner Tent.
3. Referring to the diagram below, peg the 2 back corners of the Inner Tent groundsheet in close proximity to points C & D. You may have to rearrange the mudskirt of the Annexe slightly to do this.
4. Attach the tapes/elastics from the 2 back Inner Tent roof tabs around the corners of the Annexe frame at points E & F.
5. Now peg the 2 front corners of the Inner Tent groundsheet in close proximity to points A & B, ensuring the sides and front of the Inner Tent groundsheet are pulled taut slightly.
6. Now attach the tapes/elastics from the 2 front Inner Tent roof tabs through the 'O' Rings sewn into the Annexe at points 'O' as shown on the diagram.
7. Your Inner Tent is now ready to use!

NB. If the side panel is re-fitted or an inner tent used, please ensure that the occupants are fully aware of **"Fire Precautions"**. We strongly recommend that if young children are to sleep in the Annexe, the doorway is left unzipped to provide a quick, unhindered means of escape.

Diagram showing 520 Annexe with Inner Tent

